


Model No.PB003G Cordless Portable Band Saw



Model No.PB003G Cordless Portable Band Saw

Obj. č.	Obj. č.	Popis	Možn ost zá měny	Množ ství	Nový/ Starý	Poznámka 1	Poznámka 2
001	412485-2	Wheel cover		1		kryt	
002	256689-4	čep 4 3901		2			
003	961017-7	zajišťovací kroužek E-3		2		zaji	
004	265484-1	šroub 6x18 = old 265322-7		2			
005	267173-4	Flat washer 6		2			
006	137424-8	WHEEL A ASSY		1			
006		INC. 8					
007	136765-9	WHEEL B ASSEMBLY		1			
007		INC. 9					
008	424589-8	Rubber tire		1		guma DPB181	
009	424589-8	Rubber tire		1		guma DPB181	
010	267164-5	Scheibe 15		1		podlo	
011	162564-3	Slide plate		1		kluzna deska	
012	911138-5	Pan head screw M4X20 WR		2			
013	268241-6	Pin 6		1			
014	1412U9-3	Frame complete		1			
C10	263005-3	vymezovací čep 6		1			
015	234313-9	Compression spring 9		1			
016	262130-7	Urethane ring 4		2			
017	214408-4	Plane bearing 30		1			
018	326351-6	Lever shaft		1			
019	459084-9	Lever holder		1		dr	
020	911138-5	Pan head screw M4X20 WR		4			
021	265382-9	Hex. socket head bolt M5X20		1			
022	231955-0	zajišťovací pružina 12		1		zaji	
023	271462-1	Lever 54		1		p	
024	911138-5	Pan head screw M4X20 WR		1			
025	267010-2	podložka 5		2		podlo	
026	212199-1	Needle bearing 510		1		lo	
027	256155-1	čep 5		1			
028	911138-5	Pan head screw M4X20 WR		2			
029	162815-4	Hook		1		h	
030	251337-0	šroub		2			
031	210187-2	Ball bearing 696ZZ		4		lo	
032	210187-2	Ball bearing 696ZZ		1		lo	
033	256033-5	čep		1			
034	312J78-4	Upper holder		1			
035	911138-5	Pan head screw M4X20 WR		2			
036	251337-0	šroub		2			
037	162815-4	Hook		1		h	
038	210187-2	Ball bearing 696ZZ		4		lo	
039	210187-2	Ball bearing 696ZZ		1		lo	
040	256033-5	čep		1			
041	312J77-6	Lower holder		1			
042	346728-9	Stopper plate		1			
043	253194-2	podložka		1		podlo	
044	265E87-1	Hex. head bolt M5X15		1			
045	271490-6	Lever 40		1			

046	911118-1	šroub M4x12		1			
047	266213-5	Hex. socket set screw (flat point) M5X12		1			
048	620R06-6	LED circuit		1		LED okruh	
049	1832C5-9	HANDLE SET		1			
C10	263005-3	vymezovací čep 6		2			
049		INC. 54					
050	412551-5	Lock off button		1	*	p	
050-1	4137J5-7	Lock off button	<	1	*		
050-2	4137P6-7	LOCK OFF BUTTON	<	1			
051	231433-0	vinutá pružina		1		vinut	
052	651486-7	Switch C3JW-4B-R		1		vyp	
053	911138-5	Pan head screw M4X20 WR		4			
054	1832C5-9	HANDLE SET		1			
C10	263005-3	vymezovací čep 6		2			
054		INC. 49					
055	620T33-5	Dial circuit		1			
056	632W78-9	Terminal unit		1	*		
056-1	632W78-9	Terminal unit	O	1			
057	266130-9	šroub PT 3X		8			
058	266130-9	šroub PT 3X		5			
059	1832D4-8	MOTOR HOUSING SET		1			
059		INC. 61					
060	911188-0	Pan head screw M4X60 WR		2			
061	1832D4-8	MOTOR HOUSING SET		1			
061		INC. 59					
062	911188-0	Pan head screw M4X60 WR		2			
063	620T32-7	Controller		1			
064	652069-6	Flat head screw M3X6		3			
065	266490-9	Pan head tapping screw 2X6		3			
066	319980-2	Gear housing		1		obal stroje	
067	211247-3	Ball bearing 6002DDW		2			
068	257348-3	Ring 15		1			
069	140T74-0	Spindle complete		1		v	
070	226924-4	Spur gear 11		5		ozuben	
071	226922-8	Internal gear 39		1		kolo	
072	140M81-1	Spur gear 16 complete		1		ozuben	
073	226923-6	Spur gear 13		3		ozuben	
074	140M80-3	Spur gear 14B complete		1		ozuben	
075	226923-6	Spur gear 13		3		ozuben	
076	226921-0	Internal gear 40		1		kolo	
077	253474-6	Lock washer		1		p	
078	619628-9	Rotor		1		rotor	
079	629D69-5	Stator		1			
080	8154W5-0	PB003G NAME PLATE		1			
081	8154W6-8	PB003G SERIAL NO. LABEL		1			
082	122B60-5	Hook assembly		1		h	
083	911223-4	šroub M5x16		2			
084	264013-7	Hex. lock nut M5-8		2			
085	941102-2	podložka 5		4		podlo	
086	327637-1	Guard		1		chr	
A01	B-40559	PORTABLE BANDSAW BLADE 18T		1			

		PI					
A02	783202-0	klíč inbus 4		1		kl	
F02	1917F0-6	Stand set		1	*		
F02-1	1917F0-6	Stand set	O	1			
F03	191897-9	řezný vosk 2107FK		1			
F04	821950-4	PLASTIC CASE		1			

Prosím uveďte objednáací číslo dílu v objednávce

Datum tisku 15. 05. 2026