


Číslo typu HR1841F 18MM ROTARY HAMMER



Položka	Číslo dílu	Popis	Změn	Množstv	N/O	Možnost 1	Možnost 2	Poznámka
001	286037-3	CAP 34		1				
002	961057-5	segrovka vnější S-17		1				
003	253377-4	FLAT WASHER 17		1				
004	457214-6	CHUCK COVER		1				
005	257416-2	RING 21		1				
006	216022-2	kulička = old 183013		2				
007	346177-0	podložka		1				
008	232347-6	CONICAL COMP. SPRING 21-29		1				
009	921923-8	šroub M8x120=old921919-9=ols265580-		1				
010	417911-6	GRIP BASE		1				
011	266053-1	šroub 4x35=new266351-3		4				
012	144271-0	GEAR HOUSING COMPLETE		1				
C10	213636-8	OIL SEAL 25		1				
C20	211375-4	Kugellager		1				
013	213278-8	o-kroužek 17		1				
014	161568-2	LOCK BUTTON COMPLETE		1				
015	232344-2	COMPRESSION SPRING 3		1				
016	161569-0	CHANGE LEVER COMPLETE		1				
017	158057-6	rukojeť 36 HR2230/2460		1				
C10	931402-8	matka M8 = old 481003		1				
018	457356-6	PLATE		1				
019	853K20-7	HR1841F SERIAL NO. LABEL		1				
020	961135-1	segrovka		1				
021	267304-5	FLAT WASHER 25		1				
022	232360-4	COMPRESSION SPRING 25		1				
023	221494-8	SPUR GEAR 44		1				
024	327039-1	DRIVING FLANGE		1				
025	216019-1	kulička pr.3mm		3				
026	326886-7	TOOL HOLDER		1				
027	326887-5	IMPACT BOLT		1				
028	213117-2	o-kroužek 11		1				
029	253380-5	FLAT WASHER 13		1				
030	326888-3	RING 10		1				
031	232357-3	COMPRESSION SPRING 10A		1				
032	327038-3	CUP SLEEVE		1				
033	233942-5	pružina HR1830/F/BHR162		1				
034	267175-0	podložka 6914D		1				
035	345681-6	spojovací díl		1				
036	347128-6	CHANGE PLATE		1				
037	233458-0	COMPRESSION SPRING 32		1				
038	326889-1	STRIKER		1				
039	213832-8	O-RING 13		1				
040	326890-6	PISTON CYLINDER		1				
041	347127-8	GUIDE PLATE		1				
042	324612-8	čep		1				
043	232361-2	CONICAL COMP. SPRING 6-13		1				
044	347130-9	SPRING GUIDE		1				
045	211016-2	kuličkové ložisko 626LLB		1				

Položka	Číslo dílu	Popis	Změn	Množstv	N/O	Možnost 1	Možnost 2	Poznámka
046	221495-6	SPUR GEAR 12		1				
047	326892-2	CAM SHAFT		1				
048	326891-4	CLUCTH CAM		1				
049	219029-7	SWASH BEARING 9		1				
050	253733-8	podložka 9		1				
051	251510-2	H. S. HEAD BOLT M3X12 WITH WRM		2				
052	253381-3	FLAT WASHER 3		2				
053	347129-4	SPRING PLATE		1				
054	221496-4	HELICAL GEAR 23		1				
055	211016-2	kuličkové ložisko 626LLB		1				
056	232359-9	COMPRESSION SPRING 7		2				
057	213833-6	O-RING 60		1				
058	144270-2	INNER HOUSING COMPLETE		1				
059	213118-0	o-kroužek 12 HR5211C/5210C		1				
060	326893-0	RING 9		1				
061	210162-8	BALL BEARING 609LLU		1				
062	267231-6	podložka 9 HR2020		1				
063	513989-8	ARMATURE ASS'Y 240V		1				
D10		INC. 59-62,64,65						
064	681670-0	izolační podložka =old 681652-2		1				
065	210023-2	kuličkové ložisko 627 DDW		1				
066	267804-5	podložka HR2230/2460/2470		1				
067	457350-8	BUFFLE PLATE A		1				
068	266069-6	šroub křížový 9403		2				
069	633994-0	FIELD		1				
070	256347-2	ROD 4		3				
071	457352-4	MOTOR HOUSING A		1				
072	232358-1	COMPRESSION SPRING 10B		1				
073	424951-7	BELLOWS		1				
074	457355-8	HANDLE		1				
075	257417-0	SLEEVE 8		2				
076	251530-6	TAPPING SCREW 4X18		2				
077	194722-3	uhlíky CB-459 GA5030/GA4530		1				
078	632K41-0	BRUSH HOLDER UNIT		1				
079	631937-6	LIGHT CIRCUIT		1				
080	266326-2	šroub 4x18=new265995-6		3				
081	457354-0	HANDLE COVER		1				
082	266385-6	TAPPING SCREW 4X14		1				
083	687682-1	STRAIN RELIEF		1				
084	682566-8	ochranná průchodka		1				
085	665890-4	přívodní kabel 1.0-2-4.0		1				
086	651086-3	SWITCH		1				
087	853K16-8	HR1841F NAME PLATE		1				
088	813E00-9	CLEAR LABEL		1				
A01	415486-9	hloubkový doraz		1				
A02A	821703-1	PLASTIC CASE		1				
C10	162315-4	LATCH		2				
C20	324679-6	SHAFT		1				

