


Číslo typu UH200D AKU PLOTOSTŘIH 200MM



Položka	Číslo dílu	Popis	Změn	Množstv	N/O	Možnost 1	Možnost 2	Poznámka
001	915116-7	šroub M4x12		1				
002	140599-4	PROTECTOR COMPLETE		1				
C10	819948-3	CAUTION LABEL		1				
003	188830-0	HOUSING SET		1				
C10	931102-0	matka M4		1				
C20	346275-0	PLATE		2				
D10		INC.27						
004	345998-7	plech nastavení DF030DWE/TD090DWE		1				
005	643817-4	TERMINAL		1				
006	452438-9	LOCK OFF BUTTON		1				
007	231473-8	Compression Spring 4		1				
008	688131-1	filtr MT240/HM1801/1810/HR24=old6881		1				
009	135383-0	CONTROLLER ASSY		1				
C10	654069-2	Receptacle		4				
D10		INC.8						
010	451812-8	LOCK LEVER		1				
011	651944-3	přepínač=new650593-3		1				
012	231473-8	Compression Spring 4		1				
013	417564-1	SWITCH LEVER		1				
016	451814-4	DUST GUARD		1				
017	268254-7	PIN 6		1				
018	261122-3	WASHER 6		1				
019	268256-3	PIN 4		2				
020	227728-7	HELICAL GEAR 47		1				
021	165609-6	CRANK COMPLETE		1				
022	629877-0	DC MOTOR		1				
023	268076-5	PIN 6		1				
024	261122-3	WASHER 6		1				
025	226831-1	GEAR 12-31		1				
026	261122-3	WASHER 6		1				
027	188830-0	HOUSING SET		1				
C10	931102-0	matka M4		1				
C20	346275-0	PLATE		2				
D10		INC.3						
028	266429-2	TAPPING SCREW 3X16		5				
029	867914-4	UH200D NAME PLATE		1				
030	195272-1	nože na plotostřih		1				
031	140451-6	UNDER COVER COMPLETE		1	*			
031-1	140451-6	UNDER COVER COMPLETE	<	1				
A01	451816-0	kryt nože UH200D		1	*			
A01-1	458342-0	BLADE COVER	O	1				
A02	195279-7	CHIP RECEIVER SET		1				
C10	252656-7	THUMB NUT M4		2				
A03B	***DC10WA	DC10WA BATTERY CHARGER		1				
A04B	194550-6	baterie BL1013 10,8V/1,3Ah Li-Ion		1				
A05B	195267-4	SHEAR BLADE ASSEMBLY SET		1				
A06B	325896-1	BASE FRAME		1				
A07B	451813-6	CHANGE LEVER		1				

